

CE-6000 Specification

1、 Model

1. Material code

CE-6002n-100V300A-H

2、 Channels information

1. Channels quantity

Channels quantity in
one unit

2

2. Main channel

Channel feature

Constant current source and constant voltage source
dual closed loop controlChannel control
mode

Independent control

Channel parallel
connectionSupport max 4 channels parallel mode. Pulse and SIM
tests will be disabled in channels parallel mode.

3、 Power grid side parameters

1.Input power

AC380V \pm 15% 50/60 \pm 5Hz

2.Power factor

 \geq 99%(Full load)

3.THDi

 \leq 5%(Full load)

4.Input resistance

 \geq 1M Ω

5.Input power

70.6KW

6.Input current

107.3A/single

7.Overall system
efficiency(Max)

90%

8.Noise

 \leq 65dB9.Voltage and current
samplingFour-wire connection(same port for charging and
discharging)10.Power control module
type

MOSFET

11.Input power wiring
method

Three-phase-five wire system

12.Power input protection

Anti-surge, anti-silos, anti over or under frequency, anti
over or under voltage, anti phase absence, etc.

4、 Functions and performances

1. Voltage

Output range

Charge:0V~100V

Discharge:3V~100V

Min discharge
voltage

3V

	Accuracy	±0.02% of FS
	Resolution	24bit
2. Current	Output range	1.5A~300A
	Accuracy(independent range)	±0.05% of FS
	CV cut-off current	300mA
	Resolution	24bit
3. Power	Single channel output power	30KW
	Whole machine output power	60KW
4. Time	Current response time	≤3ms
	Current conversion time	≤6ms
	Min. step time	0.1s
5. Charge/Discharge modes	Charge/Discharge modes	CCC, CVC, CC-CVC, CPC CCD, CVD, CPD, CRD
	Cut-off condition	Voltage, Current, ΔTime, Capacity, -ΔV
6. Simulation	Charge	Current, Power
	Discharge	Current, Power
	Switch	Support continuous switching between charge and discharge
	Cut-off condition	Time, step line
	Steps file lines	1,000,000
7. Pulse Mode	Charge	Current, power
	Discharge	Current, Power
	Min pulse	100ms
	Pulse counts	Up to 32
	Charge and discharge switch	supported
	Cut-off condition	Voltage, ΔTime
8. DCIR		DCIR by calculation
9. Safely protection	Software protection	Power off data protection
		Offline mode function
		Safety protection conditions can be set, including: voltage lower limit, voltage upper limit, current lower limit, current upper limit, delay time, etc.
Hardware protection	Anti-reverse connection, over-voltage, over-current, over-temperature, etc.	
5、 Data management and analysis		
1. Step setting method		Form editing

2. Data report	Recording conditions	Minimum time interval: 10ms(connected with AUX channel:100ms)
		Minimum voltage interval: 0.2V
	Recording frequency	Minimum current interval: 0.6A 100Hz(connected with AUX channel:10Hz)
3. Database		MySQL database
4. Data output		Excel, Txt
5. Curve type		Templates available, customization supported
6. Bar code scanning		Support bar-code scanning function
		Management and traceability of historical data
6、 Communication		
1. Host computer communication		TCP/IP protocol
2. Communication port		Ethernet
3. Communication baud rate of the testers		1M
4. Host computer communication baud rate		10M~100M adaptive
5. Communication setup		Set up a LAN(local area network) through switches and routers
6. Communication expansion(optional)		Support CAN, RS485 communication and BMS communication, with DBC configuration function
7、 Environmental requirements, dimension and weight		
1. Operation environment temperature		-10°C~40°C(When the temperature is 25±10°C, the accuracy error caused by temperature change is less than 0.005% of FS per degree)
2. Storage environment temperature		-20°C~50°C
3. Operation environment humidity		≤70% RH(no moisture condensation)
4. Storage environment humidity		≤80% RH(no moisture condensation)
5. Dimension W*D*H		600*800*1800(mm)
6. Weight		about 292.5KG
7. Tester Picture(Pictures just for reference)		



8、Auxiliary test system(optional)

1. Temperature aux channels	Temperature range	Thermistor: -30°C~120°C
		Thermocouple: -200°C~260°C
	Temperature accuracy	±1°C (Length within 2m)
	Temperature resolution	0.1°C
2. Voltage aux channels	Voltage range	0V~5V
	Voltage accuracy	±0.1% of FS
	Voltage resolution	0.1mV
3. Aux Introduction	It is used to monitor the temperature of the battery surface or the tabs during the test. The aux test data can be bound with the main voltage and current data. At the same time, the measured temperature can be used as the control condition and protection condition of the test profiles.	